


# How can I address the SMS gateway of an AlarmManager/SiteManager (with GSM) from a SiteManager/Docker (without GSM) via the API?


If you operate a SiteManager or Docker Container without integrated GSM modem as main device and an AlarmManager/SiteManager with GSM modem is additionally available in your system, SMS alerting via webhooks and API can be implemented as an additional reporting path.

1. Activate the SMS gateway in the AlarmManager under **Configuration -> GSM** and assign a password for the gateway



The screenshot shows the 'SMS Gateway' configuration page. On the left, a description states: 'The SMS Gateway will send SMS message after receiving HTTP requests.' On the right, there is a toggle switch labeled 'Active' which is currently turned on. Below the toggle is a text input field labeled 'Password' containing the word 'password'. A small eye icon is to the right of the password field. At the bottom, a note reads: 'SMS-Gateway password. Set this in the request as the parameter "key".'

2. In AlarmManger, copy the API token of an administrator



The screenshot shows the user configuration page. It has four sections: 'Username\*' with a text input containing 'admin'; 'Password' with a masked text input; 'Confirm Password' with a masked text input; and 'API-Token' with a text input containing 'ADJJMeIHJ8utv6IEBmbwhOcQYsA6fsodD0koGvgV'. Each section has a descriptive hint below it: 'Please enter a unique username.', 'Please enter a password.', 'Please confirm the password.', and 'API-Token of the user'. There is an eye icon to the right of the API-Token field.

3. In SiteManager, create a webhook with the **PUT** method and the following destination url **https://<IP AlarmManager>/api/sms-gateway**
4. Select **Bearer Token** as authentication and enter the API token from AlarmManager
5. For the content of the webhook choose JSON format
6. You configure the following JSON code as content

```
{
  "key": "password",
  "recipients": [
    "+491751209712", "+4915753654543"
  ],
  "body": "In der Zone $GROUP_NAME$ ist beim Sensor $DEVICE_NAME$ ein  
$ACTIVE_ALARM_SENSOR_NAME$-Alarm aufgetreten, Messwert:  
$ACTIVE_ALARM_MEASUREMENT_VALUE$"
}
```

**You now assign the configured webhook to all desired alarm groups so that it is executed when an alarm occurs.**

## Webhook Configuration

Webhooks are HTTP Requests to external services.

☒ Active

Activate Webhook.

Name\*

Alarm-SMS

Enter a name for the Webhook.

URL\*

https://10.15.30.3/api/sms-gateway

Enter here the url which is used for the request. ATTENTION: Some parameters have to be ...

HTTP-Method

PUT

Choose here the correct HTTP-Method for the request.

Authentication

Bearer Token

Choose here, if the request needs an authentication.

Bearer Token

ADJJMeIHJ8utv6IEBmbwhOcQYsA6fsodD0koGvgV

Enter here the bearer token for authentication.

Content-Type

application/json

Choose here the Content-Type (MIME-Type) of the requests data.

Data

```
{
  "key": "password",
  "recipients": [
    "+491751209711", "+4915753654522"
  ],
  "body": "In der Zone $GROUP_NAME$ ist beim Sensor $DEVICE_NAME$ ein $ACTIVE_ALARM_SENSOR_NAME$-Alarm aufgetreten, Messwert: $ACTIVE_ALARM_MEASUREMENT_VALUES$"
}
```

Enter here the data which should be send.

Check Webhook

Webhook configuration to control the SMS gateway at the AlarmManager