

# DoorLock-WA3 wall reader (bus) - MANUAL



## ORDER-CODES:

KXC-WA3-IP1, KXC-WA3-IP2

[Datasheet KXC-WA3-IPx](#)

## Overview

Kentix IP wall readers enable contactless control of doors with a MIFARE® DESFire® RFID chip. The setup always consists of the actual wall reader and the connected Kentix [AccessManager](#). The wall reader is connected to the AccessManager via a 4-wire connection. The AccessManager itself connects directly to a Power over Ethernet (PoE) capable network switch. To control electric strikes/motor locks, the SmartRelay offers two relay outputs and, depending on the power class of the strikes, an integrated PoE splitter with 24VDC output.

## Safety instructions

### Installation

Installation and commissioning may only be carried out by trained specialist personnel in accordance with the instructions.

No modifications of any kind, other than those described in an appropriate manual, are permitted to Kentix GmbH products.

Certain levels of protection must be provided when installing Kentix equipment.

Observe the relevant regulations for installations in the respective environment.

Only operate the products within the defined temperature range.

The instructions should be passed on to the user by the person carrying out the installation.

Kentix accepts no liability for damage to the equipment or components resulting from incorrect installation. No liability is accepted for incorrectly programmed units.

Kentix shall not be liable in the event of malfunctions, damage to property or other damage.

### Use of the products, transport and storage

Protect the device during transport, storage and operation from

Protect moisture, dirt and damage.

### Battery powered products

Do not use products in potentially explosive atmospheres.

Only operate the products within the defined temperature range.

Installation and battery replacement may only be carried out by trained personnel in accordance with the instructions.

Do not charge, short circuit, open or heat batteries.

When inserting the batteries, pay attention to the correct polarity.

The devices must always be operated with the batteries intended for the product.

When changing batteries, always replace all batteries.

Dispose of old or used batteries properly.

Keep batteries out of the reach of children.

### Maintenance


Kentix devices must be checked for functionality as part of annual maintenance.

### Disposal

Electrical appliances and batteries must be disposed of separately from household waste.

## Controls

### DoorLock-WA3-V1 Front view




#### WA3 Front view

1. Touch keyboard with illuminated keypad and “arm alarm” function key
2. Touch keyboard with illuminated keypad and “disarm alarm” function key
3. Integrated RFID reader, the entire surface serves as a reading surface.

The keypad can be deactivated in the configuration screen of the wall reader (from KentixONE version 8.4.3). This can be useful if an alarm group is only to be armed or disarmed on a specific wall reader using an RFID token.

#### DoorLock-WA3-V1 Rear view




1. Connection terminals, assignment see table
2. DIP switch for configuring the address

### Terminal assignment wall reader WA3-V1

Clamp	Function	Connection to AccessManager (SmartRelay)
1	RS485 Data "A"	Terminal Block 2, Terminal 6 (A)
2	RS485 Data "B"	Terminal Block 2, Terminal 5 (B)
3	-	
4	-	
5	-	
6	-	
7	GND	Terminal Block-2, Terminal 4 ( - )
8	12-24V/DC	Terminal Block-2, Terminal 3 (+)

## KXC-WA3 Terminal assignment



1. DIP switch for configuring the address

### DIP switch wall reader WA3


DIP switch	Function
1	Address bit 0 (address 1: ON; address 2: OFF)
2	Address bit 1 (address 1: OFF; address 2: ON)
3	Address bit 2 (OFF)
4	Address bit 3 (OFF)
5	Baud rate (ON)
6	Terminating resistor*

### KXC-WA3 DIP switch

\*The terminating resistor is required for longer cable lengths (> 100m). As cable we recommend telecommunication installation cable e.g. TYPE: J-Y(ST)Y 2x2x0.8mm<sup>2</sup>.


## Connection examples

### Two wall readers with door contacts and external door openers



Wiring diagram AccessManager KXP-2-RS with 2x wall reader, 2x door opener, 2x door contact

### Two wall readers with door contacts and external power supply for the electric strikes



Wiring diagram AccessManager KXP-2-RS with 2x wall readers and external power supply for the door openers


## User and access management

The administration of users and access rights is done on the main device of the installation with KentixOne.

All information about the software is available in the [KentixONE](#) section.

## Assembly and disassembly


### Flush-mounted variant



1. Mounting bracket for flush-mounted application (included in scope of delivery)
2. Wall reader KXC-WA3
3. Locking strip


### **Surface-mounted version**





1. Mounting bracket for surface-mounted applications KXC-WA3-SMC
2. Wall reader KXC-WA3
3. Locking strip

## Dismantling



1. Insert the screwdriver into the unlocking openings and unlock the lock. Pull out the locking bar.
2. Push the wall reader upwards and lift it forwards.

## Signaling

Function	Signal and explanation
Wall reader is offline	LED flashes orange
Pine input	LED flashes blue
Access granted	short tone, LED flashes green
Door is opened by time profiles	LED lights up permanently green
Access denied	3x short beep, LED flashes red
Zone is armed	3 long tones, simultaneously LED flashes 3x red
Arming not possible	long tone, LED flashes red
Zone is armed	LED flashes red

Table signaling