

Um einen reibungslosen Zugriff auf ein Main Gerät oder einen Satelliten mittels eines vergebenen DNS Namens zu ermöglichen, ist ein Eintrag für diesen Namen in den Netzwerkeinstellungen des Gerätes nötig.

Öffnen sie KentixONE zunächst unter Verwendung der IP Adresse.

Fügen sie den konfigurierten DNS Namen für das Gerät in den Einstellungen **Netzwerk -> Einstellungen -> Zusätzlich erlaubte Adressen** hinzu. (z.B. **alarmmanager.local**)

Network Settings

DHCP  Manually

IP Address  
192.168.178.105  
Please enter the IP Address

Subnet Mask  
255.255.255.0  
Please enter the Subnet Mask

Gateway  
192.168.178.1  
Please enter the Gateway

DNS Server 1  
192.168.178.1  
Please enter the DNS-Server 1

DNS Server 2  
192.168.100.1  
Please enter the DNS-Server 2

Additional permitted Addresses  
enter DNS here|  
If you're using another IP address to control your Manager, e.g. outside your network with ...

MAC Address: 70:82:0e:12:  
Host Name: kentix-70820e12b63f.local

If you're using another IP address to control your Manager, e.g. outside your network with DynDNS, you may enter here this address to permit it. You may also provide more addresses separated by comma.