

This video shows the procedure for enrolling a wireless DoorLock BASIC, PRO and LE.

The following requirements are needed:

The KentixONE system has been installed and there is an AccessManager with radio as the main device or satellite ([System Structure - Video](#))

The DoorLock was initially activated ([Initial Startup of the SmartAccess wireless components](#)).