

# Micro-SD Karte einfügen

The SLOT for a micro SD card is located on the right-hand side of the PDU directly behind the mounting plate.  
The micro SD card must therefore be inserted into the PDU when it is removed.

The SD card is needed to perform a [mass update](#) or to save automatic data backups.



Always make sure that the SD card is correctly locked into position.

**SD-Card slot**



