

Alarm siren (SystemPort) - MANUAL



ORDER-CODES:
KFLASH1

Overview

The Kentix alarm siren is used for acoustic and visual signaling in the event of an alarm. It is suitable for both indoor and outdoor installation (IP65 protection class).

The alarm siren is equipped with a 10 m long connection cable and is connected to the SystemPort of a suitable remote station via the supplied T-adaptor. Suitable remote stations are SiteManager, AlarmManager and MultiSensor (Ethernet). The power supply is provided by the supplied power supply unit.

Safety instructions

Installation

Installation and commissioning may only be carried out by trained specialist personnel in accordance with the instructions.

No modifications of any kind, other than those described in an appropriate manual, are permitted to Kentix GmbH products.

Certain levels of protection must be provided when installing Kentix equipment.

Observe the relevant regulations for installations in the respective environment.

Only operate the products within the defined temperature range.

The instructions should be passed on to the user by the person carrying out the installation.

Kentix accepts no liability for damage to the equipment or components resulting from incorrect installation. No liability is accepted for incorrectly programmed units.

Kentix shall not be liable in the event of malfunctions, damage to property or other damage.

Use of the products, transport and storage

Protect the device during transport, storage and operation from

Protect moisture, dirt and damage.

Battery powered products

Do not use products in potentially explosive atmospheres.

Only operate the products within the defined temperature range.

Installation and battery replacement may only be carried out by trained personnel in accordance with the instructions.

Do not charge, short circuit, open or heat batteries.

When inserting the batteries, pay attention to the correct polarity.

The devices must always be operated with the batteries intended for the product.

When changing batteries, always replace all batteries.

Dispose of old or used batteries properly.

Keep batteries out of the reach of children.

Maintenance


Kentix devices must be checked for functionality as part of annual maintenance.

Disposal

Electrical appliances and batteries must be disposed of separately from household waste.

Mounting and connection

The alarm siren is connected to the SystemPort of a suitable remote station. Suitable remote stations are SiteManager, AlarmManager and MultiSensor (Ethernet). The T-adaptor is plugged in between the siren and the remote station. The third socket of the T-adaptor is used to connect the power supply of the siren.



1. Alarm siren
2. Remote station with system port (TYPE-A)
3. T-adapter
4. Power adapter KIO2
5. Power supply 24VDC

ATTENTION! The siren must not be operated on devices (SmartPDU) with the Kentix TYPE-B system port.

Configuration with KentixONE

The device is configured via the web browser in KentixONE. The device must be accessible to the central KentixONE instance on the network side. Depending on the device type, a communication key and the IP address or DHCP name of the central KentixONE instance must also be set on the device (MultiSensors, AccessManager, SmartPDU). IP cameras or IO modules, on the other hand, can be integrated directly into KentixONE.

All information about the software is available in the [KentixONE](#) section and the related documentation.

Before starting the configuration, make sure that the software on all network-compatible Kentix devices is up-to-date. The version status must match on all devices.

You can perform a software update for your KentixONE main instance and all connected

satellites at any time via “System - Update”.