How to measure a lock cylinder correctly?

In order to integrate a Kentix DoorLock-DC Basic or Pro correctly into your door, the internal and external dimensions of the locking cylinder are crucial.
When measuring and ultimately selecting the cylinder length, a number of points must be taken into account.

In the following video the whole process is explained and illustrated:

Our ordering guide as a PDF file helps to apply the determined dimensions to an order of the cylinder.

© Kentix GmbH. This file was automatically generated on 2026-11-08 00:42:51. Please visit docs.kentix.com for the latest documentation.