

An welcher Position soll der SmartXcan angebracht werden?



The SmartXcan is not intended for outdoor use!

The specified mounting height of the SmartXcan is 110 cm and an angle of 60°. This allows small persons to maintain a distance of 10 to 30 cm from the device, which is relevant for the measurement.

For mounting on a wall, the wall bracket included in the scope of delivery is used. To set up the device in free space the Kentix stand **ART: KMS-TI-FS-STAND1** can be used.

Furthermore, it is important to ensure that there are no heat sources such as lamps, heaters or other radiating devices in the field of view of the SmartXcan. These can affect the measurement.



Notice

For more details on mounting the SmartXcan, see: [SmartXcan Montage](#)